USER'S MANUAL

ORIGINAL INSTRUCTIONS

PACKAGED AIR CONDITIONER

FD series **Inverter Packaged Air-conditioners**

Ceiling cassette -4 way- (FDT)

Ceiling cassette -4 way Compact- (FDTC)

Duct connected -High static pressure- (FDU)

Duct connected -Middle static pressure- (FDUM)

Ceiling suspended (FDE)

KX•KXR **VRF** inverter multi-system Air-conditioners

Ceiling cassette -4 way- (FDT)

Ceiling cassette -4 way Compact- (FDTC)

Ceiling cassette -2 way- (FDTW)

Ceiling cassette -1 way Compact- (FDTQ)

Ceiling cassette -1 way- (FDTS)

Duct connected -High static pressure- (FDU)

Duct connected -Middle static pressure- (FDUM)

Ceiling suspended (FDE)

Wall mounted (FDK)

Floor standing -2 way- (FDFW)

Duct connected -Low static pressure- (FDUT)

Duct connected -Compact&Flexible- (FDUH)

Duct connected -High static pressure outdoor air processing unit (FDU -F)

 Consultare il manuale in dotazione con TELECOMANDO CABLATO (serie RC-EX) e TELECOMANDO SENZA FILI (serie RCN-E2, EK2)

BEDRADE AFSTANDSBEDIENING (BC-EX-reeks) en DRAADLOZE AFSTANDSBEDIENING (RCN-E2-, EK2-reeks) * Consulte o manual fornecido com o CONTROLO REMOTO COM FIOS (série RC-EX) e o CONTROLO REMOTO SEM

※ Σας παρακαλούμε να ανατρέξετε στο εγχειρίδιο που παρέχεται μαζί με το ΕΝΣΥΡΜΑΤΟ ΤΗΛΕΧΕΙΡΙΣΤΗΡΙΟ (σειρά RC-ΕΧ) και το

Ж Пожалуйста, обратитесь к руководству, которое поставляется с ПРОВОДНЫМ ПУЛЬТОМ ДИСТАНЦИОННОГО УПРАВЛЕНИЯ (серия RC-EX) и БЕСПРОВОДНЫМ USER'S MANUAL ENGLISH

MANUEL DE L'UTILISATEUR FRANCAIS

ANWENDERHANDBUCH DEUTSCH

ISTRUZIONI PER L'USO ITALIANO

MANUAL DEL PROPIETARIO ESPAÑOL

GEBRUIKERSHANDLEIDING


MANUAL DO UTILIZADOR PORTUGUÊS

> ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ ΕΛΛΗΝΙΚΑ

РУКОВОДСТВО ПО ЭКСПЛУАТАЦИИ U РУССКИЙ

TÜRKCE

NEDERLANDS



* Please refer to the manual provided with WIRED REMOTE

TÉLÉCOMMANDE SANS-FIL (série RCN-E2, EK2) Siehe bitte die mit KABEL-FERNBEDIENUNG (RC-EX-Serie) und DRAHTLOSE FERNBEDIENUNG (RCN-E2-, EK2-Serie)

mitgelieferte Bedienungsanleitung

- * Consulte el manual suministrado con el MANDO A DISTANCIA ALÁMBRICO (serie RC-EX) y el MANDO A DISTANCIA INALÁMBRICO (serie RCN-E2, EK2)
- * Raadpleeg de handleiding die is meegeleverd met de
- FIOS (série RCN-E2, EK2)
- ΑΣΥΡΜΑΤΟ ΤΗΛΕΧΕΙΡΙΣΤΗΡΙΟ (σειρές RCN-E2, ΕΚ2)

Este aire acondicionado cumple con la siguiente directiva.

ПУЛЬТОМ ДИСТАНЦИОННОГО УПРАВЛЕНИЯ (серия RCN-E2, EK2)

KULLANIM KILAVUZU

 Kütfen kablolu uzaktan kumandalı olan (RC-EX serisi) ve kablosuz uzaktan kumandalı olan (RCN-E2, EK2 serisi) modelin kılavuzuna



This product complies with following directives/regulations

U		GB	
MD	2006/42/EC	SMR S.I.	2008/1597
LVD	2014/35/EU	EER S.I.	2016/1101
EMC	2014/30/EU	EMC S.I.	2016/1091
PED	2014/68/EU	PER S.I.	2016/1105
RoHS	2011/65/EU	RoHS S.I.	2012/3032
Ecodesign	2009/125/EC	Ecodesign S.I.	2020/1528

CE and UKCA marking is applicable to the area of 50 Hz power supply

Ce climatiseur est conforme aux directives suivantes. Machines 2006/42/CE

Basse tension 2014/35/UE CEM 2014/30/UE

Équipements sous pression 2014/68/UE BoHS 2011/65/UE

Écoconception 2009/125/CE La marque CE s'applique aux régions alimentées en courant Diese Klimaanlage erfüllt die folgende Richtlinie.

Maschinen 2006/42/EC Niederspannung 2014/35/EU EMV 2014/30/EU Druckgeräte 2014/68/EU RoHS 2011/65/EU Ökodesign 2009/125/EC

Die CE-Marke gilt für Bereiche mit einer Netzstromversorgung von 50 Hz

RoHS 2011/65/UE Ecodiseño 2009/125/CE La indicación CE sólo corresponde al área de suministro eléctrico de 50 Hz

EMC 2014/30/UE

Máguinas 2006/42/CE

Baia tensión 2014/35/UE

Equipos a presión 2014/68/UE

Questo condizionatore d'aria è conforme alla seguente direttiva. Macchinario 2006/42/CE

Bassa tensione 2014/35/UE EMC 2014/30/UE Apparecchiature a pressione 2014/68/UE

RoHS 2011/65/UE Ecodesign 2009/125/CE Il marchio CE è applicabile alla fascia di alimentazione 50 Hz.

Deze airconditioner voldoet aan de volgende richtlijn. Machine 2006/42/EC Laagspanning 2014/35/EU EMC 2014/30/EU Drukapparatuur 2014/68/EU RoHS 2011/65/EU Ecodesign 2009/125/EC CE-markering is van toepassing op het gebied met een netstroom van 50 Hz.

Este ar condicionado está em conformidade com as seguintes directivas. Máguinas 2006/42/CE

Baixa tensão 2014/35/UE EMC 2014/30/UE

Equipamentos sob pressão 2014/68/UE RoHS 2011/65/UE

Concessão ecológica 2009/125/CE

A marca CE aplica-se à zona de fornecimento de energia a

Το συγκεκριμένο κλιματιστικό συμμορφώνεται προς καθεμιά από τις οδηγίες που ακολουθούν.

2006/42/ΕΚ περί μηχανημάτων 2014/35/ΕΕ περί χαμηλής τάσης

2014/30/ΕΕ περί ηλεκτρομαγνητικής συμβατότητας (ΕΜC)

2014/68/ΕΕ περί εξοπλισμού υπό πίεση 2011/65/EE RoHS

2009/125/ΕΚ περί οικολογικού σχεδιασμού Το σήμα CE ισχύει μόνον σε περιοχές όπου η τροφοδοσία είναι 50 Hz.

PSB012A024D

Thank you very much for your purchase of this packaged air conditioning system produced by Mitsubishi Heavy Industries. Please read through this manual before using the product and use the product appropriately according to the instructions in the manual. After you have read the manual, store it with the warranty certificate in a safe place.

This Product contains fluorinated greenhouse gases.

Do not vent R32 into the atmosphere: R32 is a fluorinated greenhouse gas with a Global Warming Potential (GWP) = 675.

Do not vent R410A into the atmosphere: R410A is a fluorinated greenhouse gas with a Global Warming Potential (GWP) = 2088.

Refer to a label on outdoor unit for the weight of fluorinated greenhouse gas and CO₂ equivalent.

The emission sound pressure level from each Indoor unit and Outdoor unit is under 70 dB(A) except for top flow type Outdoor unit.

Regarding top flow type Outdoor unit, refer to the attached sheet with sound pressure level.

■ SAFETY PRECAUTIONS.

■ HOW TO USE

< WIRED REMOTE CONTROL (RC-E series) >	
NAMES AND FUNCTIONS OF REMOTE CONTROL BUTTONS	!
HOW TO OPERATE	!
HOW TO PERFORM THE TIMER OPERATION	(
THE SELECTION OF TIMER MODE	
SETTING THE TIME	(
SLEEP TIMER MODE	
OFF TIMER MODE	
ON TIMER MODE	
WEEKLY TIMER MODE	
TIMER CANCELLATION MODE	10
HOW TO OPERATE IN SILENT MODE	1
HOW TO ADJUST THE LOUVER	1
HOW TO SET THE AIR FLOW DIRECTION	12
AIROUTLET SELECTION	12
HOW TO OPERATE VENTILATION	10
FOR COMFORTABLE USE	13
INSPECTION DISPLAY, FILTER SIGN, AIR CONDITIONER NUMBER, STANDBY, ROOM TEMPERATURE AND	
BACK UP DISPLAY	13
TROUBLE SHOOTING	14
NOTICE	
PREPARATION OF HEATING	14
AUTO RESTART	14
SETTING TO DISABLE BUTTON OPERATION	1
INSTALLATION, RELOCATION, AND INSPECTION MAINTENANCE	19
OPERATION RANGE	19
MAINTENANCE AND INSPECTION GUIDELINE OF MAIN PARTS OF PACKAGED AIR CONDITIONER	10

SAFETY PRECAUTIONS

- ■Please read these
 "SAFETY PRECAUTIONS"
 before starting to use
 this product and use the
 product appropriately
 according to the
 instructions.
- ■The precautions provided here are classified into "A DANGER" and "
 ⚠ CAUTION". The "

 DANGER" sections describe potentially hazardous situations that may lead to serious outcomes such as death and serious injuries if the product is mishandled. Note, however, that depending on the situation, the items listed in the "A CAUTION" sections do also have the potential of causing serious outcomes. Both warnings and cautions provide you important information related to safety; please make sure to observe them.
- The symbols used throughout the main text of this manual have the following meaning.

- △ marks mean danger, alarm, and caution. The specified prohibited item is described in the triangle. The left mark means "Shock hazard alarm".
- Omarks mean prohibited items. The specified prohibited item is described in the circle or in the vicinage.
- marks mean compulsory action or instruction. The specified prohibited item is described in the circle. The left mark means "Earth is needed".
- The user's manual should be read carefully.
- There is information included in the user's manual and/or installation manual.
- A service personnel should be handing this equipment with reference to the installation manual.
- After you have read the manual, always store it where other users can refer to at any time. If a new owner takes over the system, make sure to pass this manual.

ENGLISH

Following precaution is only for R32.

This equipment uses flammable refrigerants. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.

When the power breaker is on, pay attention to the rotation of the fan. If the refrigerant sensor detects a refrigerant leak, the fan will rotate automatically and may cause injuries.

This unit is equipped with electrically powered safety measures and a leak detection system. To be effective, the unit must be electrically powered at all times after installation, other than when servicing.

↑ DANGER

Strict compliance of the domestic laws must be observed when disposing the appliance.

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

The appliance shall be stored in a room without continuously operating

ignition sources (for example: open flames, an operating gas appliance or an operating electric heater.

Do not pierce or burn.



Be aware that refrigerants nay not contain an odour.

The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.

The staff in servicing operations must hold the national qualification or other relevant qualifications.

This unit should be installed in rooms which exceed the floor space specified in installation sheets of indoor/outdoor unit. Refer to the installation sheet.

INSTALLATION PRECAUTIONS

⚠ DANGER

Make sure to have the installation done by your dealer or a specialist.

If you install by yourself and the unit is not properly installed, water leakage, electric shock, fire and injuries caused by the drop of the unit may occur.

The preventive measures that the density of leaked refrigerant does not exceed

the limit is necessary in case of installing the unit in a small room.

The leakage of refrigerant may cause oxygen deficiency accident. Consult your dealer for the measures.

⚠ CAUTION

Make sure to perform grounding work.



Do not connect grounding wire to any gas pipe, water pipe, conductor rods or telephones. Incomplete grounding may cause electric shock through leakage of electricity.

Make sure to mount a leakage breaker.



Otherwise electric shock may occur. Please consult your dealer or a specialist for the mounting.

Do not mount where flammable gas leakage can happen.

If leaked gas stagnates in the unit, the gas may cause fire.

Make sure to layout the drain pipe so that the water is completely drained.

Otherwise, water may leak and wet household goods.

OPERATION PRECAUTIONS

A DANGER

The appliance is not to be used by persons (including children) with

reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

This appliance can be used ① by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children being supervised \bigcirc not to play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

Do not expose yourself directly to cooled air flow for a long time or cool too much.

It may be cause of deconditioning or health disorder.

Do not insert fingers or sticks into the air inlet or outlet grilles.

It may cause injuries because of the fan rotating at high speed.

If the unit has been submerged under water



due to a natural disaster such as flood or typhoon, consult your dealer before using it again.

If you use it as it stands, it may lead to failure, electric shock or fire.

If any abnormal symptom (scorched flavor etc.) is found, cut off the power and stop the operation.
Then consult your dealer.

If you use it as it stands, it may lead to failure, electric shock or fire.

One of the causes of poor **()** cooling or poor heating may be refrigerant leakage. Please consult your dealer.

If the repair requires additional refrigerant, determine the service with the service staff. The refrigerant of air conditioner is not toxic. Normally the refrigerant does not leak. But if it leaks and contacts fire such as fan heater, space heater or cooking heater, it may produce toxic chemicals.

Do not insert fingers or sticks even if air blower does not operate.

It may suddenly operate and cause injuries.


This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

A CAUTION

Do not use for particular purpose such as the storage of food, animals and plants, precision apparatus and arts etc.

Storage goods may degrade.

Do not operate the button with wet hand.



When a burning appliance (1) is used together with the unit, ventilate frequently.

If ventilation is not sufficient, it may cause oxygen deficiency accident.

Do not place a burning appliance where the air flow from the unit is directly blown.

It may cause the imperfect combustion of the equipment.

Make sure that the unit installation foundation is not damaged due to long-term use.

If it is left to stand, the unit may fall down causing injury.

Do not wash the unit with water, nor place a vase with water on the unit.

It may cause electric shock or ignition.

Do not install the unit where the air flow is directly blown to animals and plants.

They may suffer from adverse effect.

Before cleaning, make sure to stop operation and cut off the power.

The fan inside rotates at high speeds.

Make sure to use proper size of fuse.

Using steel wire or copper wire may lead to failure or fire.

Do not store a flammable spray etc. near the unit, nor blow directly to the unit.

It may lead to fire.

Before maintenance, make sure to stop operation and cut off the power.

The fan inside rotates at high speeds.

When the unit isn't used for a long-term, cut off the power.

The accumulation of dirt may lead to heat generation or fire. But, before resuming the operation, turn on the unit for six hours beforehand to save harmless.

Do not place any other electric appliances or household goods below or around the air conditioner.

Dripping from the unit may lead to failure or contamination.

Do not touch the aluminum fin.

Otherwise it may lead to injuries.

Do not clean the inside of the indoor unit by yourself. Make sure to consult your dealer or user inquiry counter specified by our company.

If you select incorrect detergent or improper method, resin parts may be damaged and lead to water leakage. If the detergent is dropped on the electric component or motor, it may lead to failure, smoking or ignition.

Do not place objects on the outdoor unit, nor mount on it.

It may lead to injuries resulting from dropping or falling.

During the operation or maintenance, do not use an unstable footrest.

It may lead to injuries resulting from falling.

Be careful so that the dust does not get into your eyes when removing the air filter.

Do not operate the air conditioner while the air filter is removed.

Piled up dust may lead to malfunction.

During thunderstorm, stop the operation and turn off the switch.

A lightning strike may lead to failure.

3

After several seasons of operating, inspections and maintenances are required except routine care and cleaning.

Accumulated dirt or dust inside the indoor unit may cause odor, water leakage through the clogging of water discharging pipe for dehumidification. Specialized information and skills are required for inspections and maintenances. Therefore contact your dealer.

Do not place any object around the outdoor unit, nor allow fallen leaves to pile up.

Fallen leaves may induce insects and worms in them, and they may lead to failure, ignition or smoking by touching electric components.

Do not use with inlet/ outlet grilles or other panel removed.

Otherwise, it may lead to injuries.

Do not operate or stop the ounit by using the power supply switch.

It may lead to fire or water leakage.

If auto restart is set effectively, the fan may rotate suddenly causing injuries.

Do not touch blowout port \bigcirc when the swing louver moves.

Otherwise, it may lead to injuries.

Do not strain the remote control cord.

A part of core wire may be cut off causing electric leakage.

Do not use water heater etc. near the indoor unit or remote control.

If a Vapor-generating appliance is used near them, it may lead to water drop causing electric leakage or short circuit.

Do not use the unit where powder or fiber is floating.

Fine powder or fiber passing through the air filter may stagnate inside the unit and lead to electric leak or short circuit.

Do not place objects under the unit which must avoid being exposed to water.

Over 80 percent humidity or the clogging of drain pipe may damage them through dew dropping.

When the refrigerant leaked accidentally, turn off the stove, or other, and ventilate air sufficiently.

PRECAUTIONS FOR RELOCATION OR REPAIRING

⚠ CAUTION

Never perform any modification. Contact your dealer for repairing.

Improper repairing may lead to water leakage, electric shock or fire. Normally the refrigerant does not leak. But if it leaks and contacts fire such as fan heater, space heater or cooking heater, it may produce toxic chemicals. When repairing refrigerant leakage, determine the service with the service staff that the repair has been finished without fault.

If it is required to relocation and reinstall the unit, consult your dealer or a specialist.

Improper installation of air conditioning unit may cause water leakage, electric shock and/or fire.

Before repairing or checking indoor unit, be sure to turn off "Indoor unit power supply breaker".

It can result in electric shock or injury due to rotation of indoor unit fan if you perform check or repair with the "Indoor unit power supply breaker" turned on.

Place the panels removed **()** for repairing or checking on the stable spot.

Otherwise, dropping or falling may lead to injury.

0

When you change the layout of your room, consult a dealer or a specialist.

Safety measures and detection systems may not work properly.

PRECAUTIONS FOR WASTE DISPOSAL




Your Air Conditioning product may be marked with this symbol. It means that waste electrical and electronic equipment (WEEE as in directive 2012/19/EU) should not be mixed with general household waste. Air conditioners should be treated at an authorized treatment facility for re-use, recycling and recovery and not be disposed of in the municipal waste stream. Please contact the installer or local authority for more information.

HOW TO USE< WIRED REMOTE CONTROL (RC-E series) >

NAMES AND FUNCTIONS OF REMOTE CONTROL BUTTONS < WIRED REMOTE CONTROL (RC-E SERIES) >

Wired remote control (RC-E series) The figure below shows the remote control with the cover opened. Note that the items in the liquid
crystal display (LCD) area are shown for explanation purpose.

Pull the cover downwards to open.



* IN case of FDU-F

The setting temperature of the remote controller indicates the outdoor temperature while operating thermostat ON/OFF.

Unit specifications


Item	Description
Product dimensions	120 (W) x 120 (H) x 19 (D) mm (not including protruded section)
Weight	0.20 kg
Power supply	DC 18 V
Power consumption	0.6 W
Usage environment	Temperature: 0 to 40 °C
Material	Casing: ABS

HOW TO OPERATE (Dehumidifying operation is prohibited for FDU-F.) < WIRED REMOTE CONTROL (RC-E series) >

ATTENTIO

In order to protect both indoor/outdoor air conditioners, keep the power supply on for six hours before initial operation. (The
crank case heater is energized in order to heat up the compressor.) Do not turn off the power supply. (Power is distributed to
the crankcase heater, even if the compressor is stopped. This keeps the compressor warm, and prevents failures caused by
accumulation of liquid refrigerant.)

Operation mode



■ Guideline for room temperature setting

COOL	26 to 28°C
DRY	21 to 24°C
HEAT	22 to 24°C
FAN	Setting unnecessary

 The settings of operation change, temperature and air flow volume adjustment can be changed even when the air conditioner is stopped. When a button is pressed while the operation is stopped, the corresponding display is turned on and you can change the setting. The display lights for three seconds after changing the setting, and then turns off automatically.

ATTENTION

- The display of "OPERATION MODE INVALID" flashes and the operation is switched to "Fan" in the following case because the operation modes do not match.
- When other indoor units are operating in different modes (with KXR, the heat recovery system, it is possible to operate indoor units in different cooling/heating modes).
- Do not turn the air conditioning system on/off frequently.
- Do not use sharp objects to press the remote controller switches.

1 Press ①ON/OFF button.


The unit starts operating.

2 Press MODE button.

The range of operation mode is displayed according to the model of indoor unit.

Every time the button is pressed, the display changes in the following order dry \rightarrow cool \rightarrow fan \rightarrow heat. (\rightarrow auto)*

- * In the multi-system, the automatic operation can be selected in case of the heat recovery system KXR only. The automatic operation cannot be selected in case of heat pump system KX.
- With auto operation, heating and cooling is automatically changed depending on difference between the setting temperature and room temperature.*



* IN case of FDU-F

The setting temperature of the remote controller indicates the outdoor temperature while operating thermostat ON/OFF.

3 Press TEMP button.

Press or button to set the room temperature.*

* IN case of FDU-F

IN Case of FDO-F

The setting temperature of the remote controller indicates the outdoor temperature while operating thermostat ON/OFF.

4 Press FAN SPEED button.

The range of fan speed modes is displayed according to the model of indoor unit.

Αt	4-speed	
At	3-speed	."\$* a_()()(→\$\$ a a()()(→\$\$ a a(d)()"
Αt	2-speed	. "\$add(-\$add()" or "\$add() ↔\$add()"
Δt	1-sneed	The operation is invalid

3 at 4-speed

The unit operates with the maximum fan speed.

5 Press DUVER button.

If the indoor unit is equipped with the auto swing function, press the DOUVER button once and current louver status is displayed.

If the indoor unit is not equipped with the auto swing function, the message "BINALID OPER" is displayed.

- For the louver operation See page 11 to 12
- 1) Press LOUVER button, and change the display to
- ① Press once while the louver is operating to display stop positions in order.
- Press the button once more at the preferred stop position to stop the louver at that position.

Effective stop position See page 11 to 12
For automatic operation: middle
For cooling/dehumidifying operation: Horizontal
For heating operation: downwards

Press ①ON/OFF button

NOTICE

- There may be a case that "SINVALID OPER" is displayed when any button mentioned in the above is pressed, but it is not a malfunction. In that case, the operation of the button is prohibited.
- When you start to operate the unit for the first time after turning the power supply on, the default settings are listed below. You can change them as you like.

Central control	. Iurneα oπ
Operation changeover	With auto mode : auto cooling
	Without auto mode : cooling
Set temperature	.23°C
Fan speed	. N and []
Louver position	. Horizontal

HOW TO PERFORM THE TIMER OPERATION < WIRED REMOTE CONTROL (RC-E series) >

THE SELECTION OF TIMER MODE



1 Press TIMER button.

The mode changes to timer mode.

"Current day of the week" and "Current time " are displayed. [EXAMPLE] Sunday : 1 o'clock in the afternoon

Display area : [$\underbrace{\mathbb{SUN}}_{\text{NON TUE}}$ WED THU FRI SAT] [$\underbrace{\mathbb{SM}}_{\text{PM}}$ [: $\underbrace{\mathbb{SM}}_{\text{Ulights}}$] (lights)

2 Press ▲ or ▼ button.

By pressing ▼ or ▲ button, it is possible to choose the item to set.

[② CLOCK SET ▼] (set to current time)

[② SLEEP TIMER♦] (Every operation stops after a certain period of time has elapsed.)

[♠ ON TIMER ♦] (The unit starts operating at the setting time.)

[WEEK] Y TIMER \$] (Timer set for each day of the week)

[TIMER CANCEL A] (Cancel the timer setting)

If you press the RESET button, timer mode ends and return to original status.

3 Press SET button.

The selected timer mode is set.

For setting of each timer mode, see the following pages.

The possible combination of the timer function is mentioned in the following table.

Combination of modes that can be set together (O: possible x: impossible)

	Sleep timer	OFF timer	ON timer	Weekly timer
Sleep timer		×	0	×
OFF timer	×		0	×
ON timer	0	0		×
Weekly timer	×	×	×	

If you select a combination of modes that cannot be set together and press the SET button, the message "SINALIO (PER (invalid operation)" is displayed for 3 seconds and then the display returns to the one selected in step 2.

Functions of each timer operation

· Sleep timer

When the specified period of time elapses, operation stops.

. settings are available, from "an hour later OFF" to "10 hours later OFF".

The unit will stop when the setting time is reached

OFF timer

The unit stops operating at the setting time. It will operate one time per setting.

· ON timer

The unit starts to operate at the setting time. The temperature can be set together. It will operate one time per setting.

Weekly timer

You can set up to four ON/OFF timers per day.
Once Weekly timer is set, it repeats every week.


NOTICE

- If you press OONOFF button while timer mode is under setting, timer mode is canceled and the display will return to the original one. Note that the setting which has not completed is canceled.
- If you have set the ON timer mode and either the OFF timer or Sleep timer mode at the same time, the OFF timer (or Sleep timer) precedes the ON timer.
- If you press the _____ Timer button and "GIWALD OPER" is displayed, the button can not be operated because the button operation is disabled. If you want to make the button effective, consult your dealer.
- If you do not press any button for several minutes after pressing the _____ Timer button, Timer mode ends and the display returns to the original one.
- When the weekly timer setting recovers from power failures, the setting data (four settings per day) remain stored, but holiday settings will automatically override the settings for each day.

HOW TO PERFORM THE TIMER OPERATION < WIRED REMOTE CONTROL (RC-E series) >

SETTING THE TIME

Timer operation is performed based on the time of the clock which is set by the following steps. Make sure to set the time to the current time correctly.



1 Press TIMER button.

The mode changes to timer mode.

"Current day of the week" and "Current time" are displayed

Display area: [SUN MON TUE WED THU FRI SAT]

[PM 1:□□]

[② CLOCK SET ▼]

2 Press SET button.

The display area shows: [SUN MON TUE WED THU FRI SAT] (♥ flashes)

[PM 1: [III] (current time)
[⑤ SET DAY]

3 Press ▲ or ▼ button.

Place the "▼" mark above the day of the week to the current

Press ▲ and ▼ mark to move to the right and the left respectively.

If you press the RESET button, the remote control will return to the previous screen and display "A CLOCK SET V":

4 Press SET button.

The day of the week is fixed, and the flashing of ▼ mark stops and lights.

The "current time" value flashes, and "♣\$\text{SET \(\text{TMER}\)" is displayed.



Press ▲ or ▼ button.

Set to the current time.

If you press the RESET button, the display is returned to the one in step 1.

6 Press SET button.

The flashing for time display stops and lights, and *© CLOCK SET OK " is displayed to show that the current time is set. Two seconds later, the display in step 1 returns, and *© NINEK SFT ** is displayed.

7 Press ①ON/OFF button.

The timer mode is finished

NOTICE


- If you press <u>ON/OFF</u> button while timer mode is under setting, timer mode is canceled and the display will return to the original one. Note that the setting which has not been completed is canceled.
- If you do not press any button for several minutes after entering the timer mode, the timer mode ends and the display returns to the original one.

SLEEP TIMER MODE

After a certain period of time has elapsed, operation

Sleep timer

The unit stops after the set time elapses.



NOTICE

- If you press ON/OFF button while timer mode is under setting, timer mode is canceled and the display will return to the original one.
- If you do not press any button for several minutes after entering the timer mode, the timer mode ends and the display returns to the original one.

- 1 Press TIMER button.
- 2 Press ▼ button once.

"⊕ CLOCK SET ▼" → "Ð SLEEP TIMER ♦"

3 Press SET button. [EXAMPLE] " / hour "flashes, "⊕ \$ SET TIMER " lights.

Press ▲ or ▼ button.

The display changes as below. Set as you like.

" / hour "⇔" ≥ hour "~" ⊆ hour "⇔" / OFF

5 Press SET button.

Sleep timer has been set.

The air conditioner will turn on if a sleep timer is set while it is

After "2) TIMER SET OK" is displayed in the display area, the display in step 2 returns.

<When "Ten hours later OFF" is set >

" III her " (lights)

"3) TIMER ŞET OK " (lights for two seconds)

" / hour " (lights)

"J SLEEP TIMER \$" (lights)


The remaining time is displayed, and changes in an hourly basis. When the setting time elapses, the unit stops operating. Every operation stops after a certain period of time has elapsed.

Press ON/OFF button. The timer mode is finished.

OFF TIMER MODE

The unit stops operating at the setting time.

This setting is effective for only once.



ATTENTION Once the OFF timer is set, it is not possible to start operation. If you would like to operate the air conditioner, press ON/OFF button before hand to turn on.

NOTICE

- If you press ONOFF button while timer mode is under setting, timer mode is canceled and the display will return to the original one.
- If you do not press any button for several minutes after entering the timer mode, the timer mode ends and the display returns to the original one.

- Press TIMER button.
- 2 Press ▼ button twice. [♠ CLOCK SET ▼] → [♠ SLEEP TIMER ♦] → [♠ OFF TIMER ♦]
- 3 Press SET button. [EXAMPLE] "OPM 4:00 "flashes, "⊕\$SET TIMER" lights.
- Press ▲ or ▼ button.

Set the time at which you want to stop the operation.

If you press ▲ or ▼ button for a while, "Hour" display is changed by one hour, and stops when you stop pressing.

If you press ▲ or ▼ button, the number in the display becomes larger or smaller by ten minutes.

5 Press SET button.

OFF timer has been set

After " TIMER SET OK " is displayed in the display area. the display in step 2 returns.

<lf set to 6:00 PM >

"● TIMER SET []K " (lights for two seconds)

" ● PM **&**: □□ "(lights)

"● OFF TIMER ◆" (lights) The unit stops operating at 6:00 PM.

The time display is also turned off.

6 Press (I) ON/OFF button. The timer mode is finished.

HOW TO PERFORM THE TIMER OPERATION < WIRED REMOTE CONTROL (RC-E series) >

ON TIMER MODE

NOTICE

original one.

displayed.

mode is under setting, timer mode is canceled and

If you do not press any button for several

minutes after entering the timer mode, the

timer mode ends and the display returns to the

• ON timer and either Sleep timer or OFF timer are


set together, the temperature of ON timer is not

• ON timer and either Sleep timer or OFF timer are

set together. OFF timer (or Sleep timer) precedes.

the display will return to the original one.

The unit starts to operate at the set time. It is possible to set temperature at which you want to start the operation. Only one setting is applicable to each operation.



- 1 Press TIMER button.
- 2 Press ▼ button for three times.

(Ø ON TIMER ♦1

3 Press SET button.

[EXAMPLE] "②AM ☐:☐☐" flashes, "告≑ SET TIMER" lights.

4 Press ▲ or ▼ button.

Set the preferred time to start the operation

If you press ▲ or ▼ button for a while, "Hour" display is changed by one hour, and stops when you stop pressing.

Set "Minute"

If you press ▲ or ▼ button, the number in the display becomes larger or smaller by ten minutes.

Press SET button.

ON timer has been set.

The left image is displayed in the display area

<lf set to 10:00 AM > "⊕^{AM}/[☐:[☐[]" (lights)

"TEMP SET ON ▼" (lights)

If you press the RESET button, the remote control will return to the previous screen.

Press ▲ or ▼ button.

Press ▼ button and "TEMP SET OFF ▲" is displayed Press ▲ button and "TEMP SET ON ▼" is displayed

Select either of the above two.

- . Go to step 7 if temperature is set.
- Go to step 9 if temperature is not set.
- 7 Press SET button.

The left image is displayed in the display area. <lf set to 10:00 AM > "(3)AM / [7] : [7] "(lights)

"27°C" (The current set temperature is displayed flashing)

"也\/\A SFT IIP "(lights)

8 Press or button to set temperature. If you press or button, the number in the display

becomes larger or smaller by 1°C. Set temperature at which you want to start the operation.

If you press the RESET button, the remote control will return to the previous screen.

Press SET button.

ON timer is set, and after "O TIMER SET DK" is displayed, the display in step 2 returns.

<lf set to 10:00 AM >

"②^{AM}/□:□□ ᡓᠯᢏ" (lights) "⊕ ON TIMER 💠" (lights)

Set temperature is displayed only in case it is set.

The unit starts to operate at setting time with set temperature. The time display is turned off.

10 Press ①ON/OFF button.


The timer mode is finished

WEEKLY TIMER MODE

Selection of Weekly timer mode

You can set up to four ON/OFF timers per day.

Note: Set time every month in Weekly timer mode.



NOTICE

- If you press ONOFF button while timer mode is under setting, timer mode is canceled and the display will return to the original one.
- If you do not press any button for several minutes after entering the timer mode, the timer mode ends and the display returns to the original one.

WEEKLY TIMER SETTING



<In case Monday is set>



[EXAMPLE]

Number 1 : (2) AM 9: [[[[]]] Number 2 : ♠ PM []:[][]

Number 3 : (1) PM /: [[[[Number 4 : ♠ 5 : □□

* Four operations can be set with only ON timer or only OFF timer.

- 1 Press TIMER button.
- 2 Press ▼ button for four times.

(② CLOCK SET ▼) → (② SLEEP TIMER ♦) → (④ DEF TIMER ♦) → (② ON TIMER ♦) → (WEEKLY TIMER ♦)

3 Press SET button.

"TMER SET T"is displayed in the display area.

4 Press ▲ or ▼ button.

By pressing ▲ or ▼ button, it is possible to choose the item to set.

"TIMER SET T" (for setting the timer)

"HOLIDAY SET \(\Dig \)" (for setting the selected day of the week to holiday)

"CHECK/CANCEL A" (for checking the timer setting and canceling

5 Press SET button.

The selected mode is fixed.

1 In the Weekly timer mode, select "TIMER SET and press SET button to confirm.

See step 1 to 5 in "Selection of Weekly timer mode" above

"SUN MON TUE WED THU FRI SAT"(▼ is flashing)

" SFT NAY" is displayed in the display area.

2 Press ▲ or ▼ button.

Set the ▼ mark above the day of the week to the day to be set for timer setting. Press ▲ and ▼ to move to the right and left respectively, ▲ and ▼ will move flashing.

If you press the ▲ button, the day ("SUN" to "SAT") indicated with

the flashing "▼" mark will change one day at a time. If you press the ▲ button when the "▼" mark is indicating "SAT", multiple "▼" marks will appear and flash above "MON" to "FRI". Press the A button again, and multiple "▼" marks will appear and flash above "SUN" to "SAT" (every day). The same schedule can be applied to all the days indicated with the "▼" marks by using this function.

Press RESET button to return to "selecting Weekly timer mode screen, and "IMERSET ▼" is displayed. See the above step 3.

3 Press SET button.

The "▼" mark above the day stops flashing and lights, which indicates that the setting is fixed.

Press ▲ or ▼ button.

Up to four schedules can be set for each day. Select the timer schedule number you want to set. Set either ON timer or OFF timer for each single operation. (See the left EXAMPLE).

Press ▼ button to make the ◀ mark next to the number flash and move downwards

Press the **A** button to move the mark upwards.

1 ◀

Press the RESET button to return to the display in step 1.

HOW TO PERFORM THE TIMER OPERATION < WIRED REMOTE CONTROL (RC-E series) >



<When " OFF TIMER " is selected>

SUN WOM THE MED THU FRI SAT

●PM 4:00

ND CE

The settings so far are effective and the display changes as shown on

Press ▲ or ▼ button.

5 Press SET button. ■ mark next to a number lights.

> Press ▼ button and "♣ OFF TIMER ▲" is displayed. Press ▲ button and "② []N TIMER ▲" is displayed.

"�ON TIMER ▼" or "♣OFF TIMER ▲" is displayed.

Select either of the above two.

Press the RESET button to return to the display in step 3.

7 Press SET button. "5 \$ SET ∏MER " is displayed

Press ▲ or ▼ button.

Set the time.

Press the RESET button to return to the display in step 5.

Press SET button.

When time display lights, the time is fixed.

In case of OFF timer setting, setting process is completed on this step.

A " " mark lights ($MON \rightarrow MON$) under the day of the week which you set and the display appears as the left image.

Proceed to "■Next setting and Exiting Weekly timer Mode" on the

In case of ON timer setting, "TEMP SET ON ▼" is displayed, proceed to step 10.

10 Press ▲ or ▼ button.

Select either "TEMP SET ON ▼" or "TEMP SET OFF A."

11 Press SET button.

In case "TENT SET OFF ▲" has been selected, ON timer setting process is completed.

A "_" mark lights (MON > MON) under the day of the week which you set and the display appears as the left image.

Proceed to "
Next setting and Exiting Weekly timer Mode" on the

In case "TEMP SET (IN ▼" has been selected, "७∨∧ SET UP " is displayed; Proceed to step 12.

12 Press the temperature setting buttons or



Set the temperature at the start of operation.

Press the reset button to return to the display "THP SET IN T".

13 Press SET button.

ON timer setting with start-up temperature has been

The value of the temperature stops flashing and lights.

A " " mark lights ($MON \rightarrow MON$) under the day of the week which you set and the display appears as the left image.

Proceed to "■Next setting and exiting Weekly timer mode" on the right page.



Next setting and exiting Weekly timer mode After "⊕\$SELECT" is displayed, "SELECT No. ▼" is displayed.



Press ▲ or ▼ button.

By pressing ▲ or ▼ button, it is possible to choose the item to set. T" (select the next timer operation number within the same day)

"DAY SET a" (select the next day) "END A" (Timer mode ends)

2 Press SET button.

If "SFI FCT No. ▼" is selected, " \$\Displayed." is displayed. Repeat step 3 and the subsequent steps of Weekly timer setting

\$\$\dagger* is selected, "♣\$\frac{1}{2} \frac{1}{2} \ Repeat step 1 and the subsequent steps of Weekly timer setting on page 8.

If "END. . " is selected, timer mode ends.

NOTICE

- If you press ONOFF button while timer mode is under setting, timer mode is canceled and the display will return to the original one.
- · If you do not press any button for several minutes after entering the timer mode, the timer mode ends and the display returns to the original one.
- · If you select a day of the week for which setting have already been made, all the timer numbers that have been set are displayed. And the details of the timer setting for the number which has "◀" mark is displayed. You can modify the selected setting by overwriting it.
- If you set ON timer and OFF timer operating at the same time, OFF timer will precede.
- . If the same two times are set for ON timer on the same day, the lower number precedes.

Display after Weekly timer modes setting

- . The day of the week set is underlined.
- current day is turned on. The ◀ mark indicates the next
- The timer operations are executed in order, and the number and time display are turned off when all the timer operations for the current day are completed.

Weekly timer Holiday Setting

It is possible to temporarily disable each day's timer setting by using the Holiday Setting. When the Holiday Setting is cancelled, the timer setting is enabled again.

HOW TO PERFORM THE TIMER OPERATION < WIRED REMOTE CONTROL (RC-E series) >



In the Weekly timer mode, select and set

"HOLTDAY SET #".

See "Selection of Weekly timer mode" step 1 to 5 on page 8.

"SUN MON TUE WED THU FRI SAT" is displayed in the display area

"In \$ SFT DAY " is displayed.

Press ▲ or ▼ button.

Move the "▼" mark displayed above the days of week to the day which you want to set as Holiday.

Press ▲ and ▼ to move to the right and left respectively.

If you press the ▲ button, the day ("SUN" to "SAT") indicated with the flashing "▼" mark will change one day at a time. If you press the ▲ button when the "▼" mark is indicating "SAT," multiple "▼" marks will appear and flash above "MON" to "FRI". Press the ▲ button again, and multiple "▼" marks will appear and flash above "SUN" to "SAT" (every day). The same schedule can be applied to all the days indicated with the "▼" marks by using this function. This can be used in case you would like to apply Holiday setting to these days.

In case press the RESET button, the remote control will return to the previous screen and display "HOLIDAY SET \$."

Press SET button.

The "▼" mark above the day stops flashing and lights, and the day set as a holiday also lights enclosed with (). Then, the following is displayed.

After the holiday setting has been completed, the display of the remote control returns to that of step 1. Repeat step 2 and 3 to continue setting further holidays.

If you set a day of the week for which no timer operation is set, "NO SETTING" is displayed for two seconds and the display returns to the one shown in step 1.

Press () ON/OFF button.

Timer mode ends.

In the Weekly timer mode, select and set

"HOLTDAY SET \$".

See "Selection of Weekly timer mode" step 1 to 5 on page 8.

2 Press ▲ or ▼ button.

Move the "▼" mark displayed above the day of week to the day on which you want to cancel Holiday setting.

Select the day of the week that has been set as holiday.

3 Press SET button.

() display is turned off and the following is displayed.

After the holiday setting has been completed, the display of the remote control returns to that of step 1. Repeat step 2 and 3 to continue canceling further holiday settings.

Press ()ON/OFF button.

Timer mode ends.

- The ▼ mark is displayed above the current day of the week.
- The display of all the timer operation numbers set for the setting number to be activated, and the set time is displayed.

NOTICE

 If you press ONOFF button while timer mode is under setting, timer mode is canceled and the display will return to the original one.

Canceling Holiday Setting

If you do not press any button for several minutes after entering the timer mode, the timer mode ends and the display returns to the original one.

9

Weekly timer Checking



In the Weekly timer mode, select and set

"CHECK/CANCEL A.".

See "Selection of Weekly timer mode" step 1 to 5 on page 8. The display shows the detailed timer operation setting information of the smallest timer operation number on the day of the week as shown on the left. (But if not set, "NO SETTING" is displayed.)

Press ▲ or ▼ button.

Detailed timer operation settings are displayed in accordance with the timer operation you have selected.

Press ▼ button to display from Sunday and the lowest timer operation number.


Press A button to display the settings in the reverse order.

Press ()ON/OFF button.

Timer mode ends

Weekly timer mode Setting Canceling

It is possible to cancel Weekly timer mode settings of each day of the week, as well as individual timer operation number. See "Timer Cancellation Mode" on the right side to cancel settings of all days of week.



If you press ONOFF button while timer mode

is under setting, timer mode is canceled and the

If you do not press any button for several

minutes after entering the timer mode, the

timer mode ends and the display returns to the

display will return to the original one.

In the Weekly timer mode, select and set "CHECK/CANCEL A."

See "Selection of Weekly timer mode" step 1 to 5 on page 8. The display shows the detailed timer operation setting information of the smallest timer operation number on the day of the week as shown on the left

2 Press ▲ or ▼ button.

Detailed timer operation settings are displayed in accordance with the timer operation you have selected

Press ▼ button to display from Sunday and the lowest timer operation number.

Press ▲ button to display the settings in the reverse order.

Select the timer operation number on a day of the week you want to cancel.

If you press the RESET button, the remote control will return to the previous screen, and display "CHECK/CANCEL ..."

3 Press SET button.

"CANCEL?" is displayed.

If you press the RESET button, the remote control will return to the previous screen, and display "\$FHFFK SFTTING".

Press SET button.

"CANCELLED" is displayed, and the displayed detail timer operation setting disappears and is canceled.

"\$CHECK SETTING" is displayed again.


Repeat step 2 to 4 to continue canceling other settings.

5 Press ①ON/OFF button.

Timer mode ends.

HOW TO PERFORM THE TIMER OPERATION < WIRED REMOTE CONTROL (RC-E series) >

TIMER CANCELLATION MODE



1 Press TIMER button.

Timer mode begins.

The current "The day of the week" and "the current time" are displayed.

2 Press ▼ button for five times.



3 Press SET button.

Timer Cancellation Mode begins.

4 Press ▲ or ▼ button.

By pressing ▲ or ▼ button, it is possible to choose the item to cancel.


If you press the RESET button, the remote control will return to the previous screen, and display "TIMER CANCEL A."

(step 2 above)

5 Press SET button.

The detailed setting of selected timer mode is displayed as

(But if not set, "NO SETTING" is displayed)



If you would like to guit cancellation, press the RESET button to return to the "ON TIMER +" display. (step 4 above)

Press SET button.

The display of the detailed timer setting is turned off, and after the message "CANCELED" is displayed for two seconds. "ЭSLEP TMR+" is displayed again. (step 4 above)

Repeat steps 4 to 6 to continue canceling timer mode settings.

NOTICE

- If you press **ONOFF** button while timer mode is under setting, timer mode is canceled and the display will return to the original one.
- If you do not press any button for several minutes after entering the timer mode, the timer mode ends and the display returns to the original one.

In case "DSLEEP TIMER ♦" , "♣ OFF TIMER ♦" or "♥ ON TIMER ♦" was : In case "WEFKLY TIMER ♣" was selected.

All the Weekly timer setting will be canceled if you proceed the following steps.

To cancel a part of the timer setting, please see "Weekly timer mode Setting Canceling" on the left side.

5 Press SET button.

The settings are displayed as shown below. (But if not set, "NO SETTING" is displayed)



If you would like to guit cancellation, press the RESET button to return to the "WFRXIY TIMER A" display, (step 4 above)

Press SET button to confirm.

The day of the week display area turns off, and after the message "CANCELLED" is displayed for two seconds, the display returns to "② SLEP TIMER♦" (step 4 above) These operation settings cancel all days of the week.

Press ON/OFF button.

Timer mode ends

NOTICE

original one.

HOW TO OPERATE IN SILENT MODE < WIRED REMOTE CONTROL (RC-E series) >


SILENT MODE

When the silent mode is set, the unit operates more silently reducing noise from the outdoor unit.

The system applies the silent operation mode at the starting time to be set, and finish it after a certain period of time has passed.

Once the system is set to operate with the silent mode, the setting is applied everyday until it is canceled.

Silent Mode Setting



Canceling Silent Mode (Setting)

Select "CANCEL SILENT &" in step 2, press SET button and silent setting is canceled ending the silent mode.

"CANCELLED" is displayed.

NOTICE

- The remote control has main-sub units, silent setting cannot be operated with sub unit.
- After the silent mode is set, the following is displayed for 3 seconds at the set time and the unit returns to the original display.

At the ON time: "SILENT MODE ON"
At the OFF time: "SILENT MODE OFF"

- If you select " ヹ゚゚゚゚゚゚゚゚゚ | "you can continue the silent mode until it is canceled. At the first ON time, the display shows "\$!!!日 MOE ON" for three seconds and returns to original display.
- If you press <u>ON/OFF</u> button while timer mode is under setting, timer mode is canceled and the display will return to the original one. Note that the setting which has not been completed is canceled.

In the timer mode, set the current day of the week and current time.

See page 6 step 1 to 7

2 Press SET button for three seconds or more.

The remote control goes into silent mode setting and the following is displayed.

"SET SILENT ■" or "CANCEL SILENT ■" (lights)

3 Press ▲ or ▼ button.

If \blacktriangledown button is pressed, "CANCEL SILENT \blacktriangle " is displayed. If \blacktriangle button is pressed, "SET SILENT \blacktriangledown " is displayed. Select "SET SILENT \blacktriangledown ".

If you press the RESET button, the remote control return to the original screen.

4 Press SET button.

The following setting is displayed



5 Press ▲ or ▼ button.

Set the "ON TIME".

• Set "Hour"

If you hold \blacktriangle or \blacktriangledown , the number in "Hour" display changes, and if you release it, the number stops changing.

Set "Minute"

If you press ▲ or ▼ button, the number in the display becomes larger or smaller by ten minutes.

If you press the RESET button, the remote control return to the "SET SILENT" v display.

6 Press SET button.

The ON TIME is set and the following is displayed.



Press ▲ or ▼ button to set the duration. Select OFF time.

When you press ▲ button, and the duration is increased by two hours as below, " こ かば " → " リ かば " → " ここ かば " → " 」 かば " → " ここ かば " →

When you press ▼ button, and the duration is decreased by two

If you press RESET button, the "ON TIME SET" display returns

8 Press SET button.

The setting is fixed and displayed.

"SET COMPLETE" is displayed, and the silent mode setting ends. The setting display turns off, and returns to original display.

HOW TO ADJUST THE LOUVER < WIRED REMOTE CONTROL (RC-E series) >

ADJUSTING WITH LOUVER BUTTON (Indoor unit with auto swing function)

[IN CASE OF FDT, FDTC, FDE, FDK, FDFW]

Press LOUVER button once, and the current status of louver is displayed.



The display during auto swing	SWING	**-
The display with the louver position fixed	STOP	1
	STOP	2 -
	STOP	3 🗀
	STOP	4 🗁

When you operate the swing louver

1 - Press DOUVER button, and change the display to "SWNG" ?"



The function of the swing louver during the heating preparation, heating/defrost

"这億 " or "Heating/Defrost" is displayed, the position of the swing louver is automatically switched to horizontal.

When the operation is switched to normal after "The heating preparation" or "Heating/Defrost" ends, the position of swing louver returns to the last setting.

When the position of the swing louver is fixed

 Press LOUVER button once while the louver is swinging, and 4 stop positions are displayed every one second in order.

"SELECT 1 → " → "SELECT 2 → " → "SELECT 3 → " SELECT 4 → "

2. Press COUVER button once when the display of the louver comes to the position you desire.

The display is switched to stop, and the position of louver is fixed.

Recommended louver fixed position

	SELECT	1
COOL•DRY	SELECT	2 🗁
HEAT	SELECT	3 77
IILAI	SELECT	4 🗇

CAUTION

- Do not move the swing louver forcibly by hands for fear that it may be damaged.
- Do not blow downwards during cooling operation for a long time for fear that dew condensation may be formed at the side panel. (In case of FDE)

horizontal position

HOW TO SET THE AIR FLOW DIRECTION (IN CASE OF FDT, FDTC, FDE, FDK, FDFW) < WIRED REMOTE CONTROL (RC-E series) >

It is possible to change the movable range of the louver on the air outlet from the wired remote control. Once the top and bottom positions are set, the louver will swing within the range between the top and the bottom positions when swing operation is chosen.


With Ceiling cassette -4 way - FDT and FDTC, it is also possible to apply different setting to each louver.

Louver No.

[for FDT]

Louver No.

[for FDTC]



NOTICE


• For FDT and FDTC type, in case the louver No. to be set is uncertain, set any louver temporarily. The louver will swing once when the setting is completed and it is possible to confirm the louver No. and the position.

After that, choose the correct louver No. and set the top and bottom nositions

· For FDE and FDK type, set louver

For FDFW type, set louver No. 2. Other settings selected have no effect





the position of the louver

1 Stop the air conditioner and press SET button and LOUVER button simultaneously for three seconds or more.

The following is displayed if the number of the indoor units connected to the remote control is one. Go to step 4.

"DATA LOADING

The following is displayed if the number of the indoor units connected to the remote control are more than one

"ტ≑ SELECT I/U" 1/0000

Press ▲ or ▼ button.(selection of indoor unit)

Select the indoor unit of which the louver is set.

[EXAMPLE] "I/U000 "I/U003


▲"⇔"I/U001 ‡ "⇔"I/U002

Press SET button. (determination of indoor unit)

Selected indoor unit is fixed.

[FXAMPI F] "[/[[00]] " (lights for two seconds)






Press ▲ or ▼ button. (selection of louver No.)

Select the louver No. to be set according to the left figure. [EXAMPLE]

"≂7⊒ №.1 "表記№.4 ▼"



Note : For FDE, select "- No. | ■" Other louver No. settings

Press SET button. (Determination of louver No.)

The louver No. to be set is confirmed and the display shows the upper limit of the movable range.

[EXAMPLE] If No.1 louver is selected, "No.1 UPPER2 ♦" ←current upper limit position

6 Press ▲ or ▼ button. (selection of upper limit

Select the upper limit of louver movable range.

"position 1" is the most horizontal, and "position 6" is the most downwards

"position --" is to return to the factory setting. If you need to change the setting to the factory setting, use "position --".

"No.1 UPPER1 ▼" (The most horizontal)

⇔ "No.1 UPPER2 ◆"

⇔ "No.1 HPPFR3 • \$" ⇔ "No.1 UPPER4 \$"

⇔ "No.1 UPPER5 ♦"

⇔ "Nn.1 | IPPFR— ▲" (Return to the position of shipment)

HOW TO SET THE AIR FLOW DIRECTION < WIRED REMOTE CONTROL (RC-E series) >



(horizontal) (1

the position of the louver

[EXAMPLE] For Upper position 2, Lower position 6

Movable

Lower

position Note: If the upper limit position number and the lower limit

range



7 Press SET button (Fixing of the upper limit position)

The upper limit position is fixed and the setting position is displayed for two seconds. Then proceed to lower limit position selection display


[EXAMPLE] "No.1 UPPER2" (lights for two seconds)

8 Press ▲ or ▼ button (Selection of lower limit position)

Select the lower limit position of louver.

"position 1" is the most horizontal, and "position 6" is the most downwards

"position --" is to return to the factory setting. If you need to change the setting to the factory setting, use "position --".



⇔ "No.1 LOWER— ▲" (return to the position of shipment) Press SET button (Fixing of the lower limit

position)

The upper limit position and lower limit position are fixed, the set positions lights for two seconds, and then the setting is completed.

· After the setting is completed, the louver which was set moves from the original position to the lower limit position, and goes back to the original position again. (This operation is not performed if the indoor unit and/or indoor unit fan is in operation.)



10 Press ①ON/OFF button.

Louver adjusting mode ends and returns to the original display.

NOTICE

- If you press RESET button during settings, the display will return to previous display. If you press ONOFF button during settings, the mode will end and the original display will return, and the settings that have not been completed will become invalid.
- · When plural remote controllers are connected, louver position setting cannot be set by slave remote control.

AIROUTLET SELECTION (IN CASE OF FDFW)

position number are set to the same position, the louver is

fixed at that position. And auto swing does not function.

It is possible to switch between the combination of upper and lower air outlets and upper air outlet. Not operable while the air conditioner is ON.

When the upper air flow is selected. UPPER AIR FLOW LED on the unit display will light green only under run.

- 1. Stop the air conditioner.
- 2. Set the upper land lower limit position of the louver No.1 from the wired remote control.

For the method of changing the setting, refer to HOW TO SET THE AIR FLOW DIRECTION on the left side.


- In case of selecting to upper air flow.
- Set the upper and lower limit position to UPPER 2 and LOWER 2. (No.1 UPPER 2 / LOWER 2)
- In case of selecting to upper and lower air flow.

Set the upper and lower limit position to UPPER 5 and LOWER 5. (No.1 UPPER 5 / LOWER 5)

AIR SELECTION button can switch the air outlets.

- 1. Stop the air conditioner.
- 2. Select the air flow from AIR SELECTION button on the unit display.
- In case of selecting to upper air flow.
 Press the AIR FLOW SELECTION button once.
 UPPER AIR FLOW LED will light for ten seconds.
- ② In case of selecting to upper and lower air flow. When UPPER AIR FLOW LED is lit by pressing AIR FLOW SELECTION button, press AIR FLOW SELECTION button once again.


UPPER AIR FLOW LED will turn off.



HOW TO OPERATE VENTILATION (WHEN A VENTILATOR IS INSTALLED) < WIRED REMOTE CONTROL (RC-E series) >

When the ventilator is set to "NO VENTI LINK"; the ventilator can be turned on and off independently regardless of the operation of the air conditioner.

When the ventilator is set to "VENTI LINK", the ventilator operation will be interlocked with the air conditioner operation.



VENTILATION OPERATION NOT LINKED WITH UNIT'S OPERATION

Press 🗐 VENTI button.

"a" is displayed, and the ventilation operation begins.



Press VENTI button again.

NOTICE

 If no ventilator is connected, no operation can be performed by pressing the ventilation button. ("@INVALID OPER" is displayed).

VENTILATION OPERATION LINKED WITH UNIT'S OPERATION

1 Press ①ON/OFF button.

If a ventilator is connected, ventilation will operate automatically. "
"" is displayed.



Press ()ON/OFF button again.

NOTICE

No operation can be performed by pressing the ventilation button.
 (***O_INVALD**) is displayed).

■ FOR COMFORTABLE USE

Clean the filter frequently

See the separate printing. (HOW TO MAINTAIN)

The filter should be cleaned when the "Filter cleaning" message is displayed, and at the ends of cooling and heating seasons.

If the filter is clogged...

- The cooling/heating capacity will get reduced. Moreover it leads to waste of electricity and larger operation noise.
- · It may cause failure.
- Dew may form and drop during cooling.

Do not block the inlet and outlet grilles of the indoor and outdoor units.

Excessive load to the unit may cause failure.

Keep moderate room temperature

Too much cooling or heating is not good for your health. It will also waste the electricity.

Block direct sunlight and prevent draft

Block direct sunlight with blinds and curtains during cooling. Close the windows and doors except when ventilation is necessary.

Adjust the air flow properly

Do not expose yourself directly to the air flow for too long time. For small animals and plants, it is harmful as well.

If you feel cold underneath your feet during heating

If the ceiling is so high that the warm air flow does not circulate underneath your feet, it is recommended to use a circulator. Consult your dealer for more detail.

Stop the operation and turn the power supply off if there are any possibility of lightning strikes during a thunderstorm.

Lightning strikes may lead to the failure of air-conditioning system.

INSPECTION DISPLAY, FILTER SIGN, AIR CONDITIONER NUMBER, STANDBY, ROOM TEMPERATURE AND BACK UP DISPLAY

< WIRED REMOTE CONTROL (RC-E series) >

WHEN THE CHECK INDICATOR LIGHT (RED) FLASHES



The air conditioner stops in the event any trouble occurs.

At the same time, the check indicator light flashes in red and the error code is displayed in the ON timer display area and the following is displayed in the display area.

"I/U000 "⇔"PROTECT STOP

(Air conditioner number)
(lights for 2 seconds by turns)

ERROR display when multiple indoor units are connected

If errors have occurred for all the connected air conditioning units. Initially, the error display shows the formation of the air conditioning unit whose number is the lowest. Errors of other air conditioning unit can be checked with the following

procedure.

1 Press AIR CON No. button.



2 Press ▲ button.

AIR CON No. and error codes are displayed in order from the lowest. Press ▼ button to display in the reverse order.

Enter AIR CON No. display mode.

3 Press ①ON/OFF button.
Return to the AIR CON of the lowest number.

If errors have occurred for some of the connected AIR CON units.

Only the units for which errors have occurred stop operating. The remote control shows the operating units.



1 Press AIR CON No. button.

AIR CON No. display mode appears.

2 Press ▲ button.

AIR CON No. are displayed in order from the lowest. And error codes are displayed on the unit in trouble.

Press ▼ button to display in the reverse

3 Press ①ON/OFF button.
Return to the AIR CON of the lowest

NOTICE

 If ①ON/OFF button is pressed once while errors are displayed, the errors display is turned off, and the stop mode returns.
 If ①ON/OFF button is pressed again, the errors are displayed.

order

ROOM TEMPERATURE DISPLAY

If room temperature display setting is activated, room temperature is displayed on the remote control display. Then air flow display turns off, but air flow adjusting button is operative. Consult your dealer for settings.



The room temperature display

WHEN THE FILTER CLEANING MESSAGE IS DISPLAYED



The "FILTER CLEANING" is displayed when the cumulative operation time reaches to the predetermined number of hours in order to notify the time for cleaning.

Clean the air filter.

See the separate printing. (HOW TO MAINTAIN)

"FILTER CLEANING" is displayed in the display area. It is displayed for one second every five seconds while the unit is running. It stays lit while the system stopped.

After cleaning

1 Press RESET button. The cumulative operation hours are reset and the "FILTER CLEANING" message turns off.

HOW TO DISPLAY AIR CON NO.

By operating AIR CON No. button, the number of the connected AIR CON unit and error codes of the units which have the record are displayed.



1 Press AIR CON No. button.

AIR CON No. display mode appears and the AIR CON of the lowest number is displayed. Other displays all turn off.

2 Press ▲ button.

AIR CON No. are displayed in order from the lowest. In addition, if any errors have occurred to the unit in the past, error codes can be found here too.

Press ▼ button to display in the reverse order.

3 Press ①ON/OFF button.

Return to the original display.

NOTICE

- The AIR CON No. can be displayed without relation to its modes of operation, stop, forcible stop due to an error.
- Buttons other than "AIR CON No." "▲" "▼" "ON/OFF" cannot be operated.

STANDBY DISPLAY

During the first operation after breaker power supply input or the recovery from power failure, "PRPARATION" can be displayed on the remote control for max 30 minutes.

The refrigerant oil protection control is activated to protect the compressor and this isn't a failure. Please wait till the display turns off



BACK UP DISPLAY

If the back up display appears on the screen,. Please contact the dealer where the unit was purchased.

The back up display is indicated per 1 second at intervals of 5 seconds when the air conditioners is in operation.



■ TROUBLE SHOOTING

Check the following items before requiring service.

ALARM SOUNDS

Refrigerant may be leaked. Contact the authorized person and your dealer.

THE UNIT DOES NOT WORK AT ALL

Is the power supply: Is there a blackout or: Is the leakage switch turned off?



is the fuse blown?

Dangerous Immediately turn off the power supply switch, and contact your dealer.

breaker activated?

: Is sunlight or other strong illumination striking the receive unit? (wireless unit)



POOR COOLING OR HEATING

Is the air filter clogged?



system KXR)

Is the swing louver horizontal (during heating)? If the swing louver is



Are there any obstacles blocking the air inlet and outlet grill?



POOR COOLING

- · Is the direct daylight
- coming into the room? · Are there any unexpected heat sources in the room?
- Are there too many people in the room?

NO AIR FLOW AT HEATING

Is "⋟®

(PREPARATION OF HEATING)" displayed in the remote control display?



If, after checking the items above, the air conditioner still does not operate normally or in the next cases, stop operating and contact your dealer.

- If the fuse and breaker blow frequently. If water drips at cooling/dehumidifying operation. If the operation or operation noise is abnormal
- · If the check indicator light flashes.

The phenomena mentioned below is not malfunction.

The air conditioning system sounds as if water is draining from it.	Sounds of rustling or gurgling may be heard when the operation is started, when the compressor is activated/ deactivated during operation, or when the operation is stopped. These are the sounds of the refrigerant flowing through the system.
Sounds of rustling or gurgling may be heard from a stopped indoor unit.	These sounds can be heard when the air conditioning system is performing automatic control.
The supply air from the indoor unit smells bad.	The supply air from the indoor unit may smell bad if the smell of cigarettes, cosmetics and/or furniture has saturated the air conditioning system.
White vapor is generated from the indoor unit during operation.	White vapor may be generated during operation if the system is used in environment where oils and fats are frequently used, such as in restaurants. In this case, consult the dealer and clean the heat exchanger.
The operation switched to fan operation during cooling operation.	The operation may switch to fan operation automatically in order to avoid frost being built up on the surface of the heat exchanger. The operation will soon return to cooling operation.
The indoor fan does not stop even when the operation is stopped in heating mode.	The indoor unit fan may continue operating for 40 seconds in order to remove remaining heat in the indoor unit. CAUTION Do not turn off the power supply until the fan stops.
The air conditioning system cannot start operating again immediately after stopping.	During the first 3 minutes after stopping operation, it is not possible to perform cooling, dehumidifying or heating operation even if the ON/OFF button is pressed to indicate 'operation.' This is because a circuit for protecting the compressor is activated (the fan is operating during this period).
No air comes out during dehumidifying operation. The air flow volume cannot be changed.	During dehumidifying operation, the fan speed is automatically controlled in low speed/stop cycle in order to avoid both drastic temperature drop and humidity rise.
The swing louver moves without any operation.	The swing louver automatically swings twice when the power supply switch is turned on. This is not a trouble. The louver also moves automatically to the horizontal position when "PREPARATION OF HEATING" is displayed.
The outdoor unit discharges water or steam during heating operation.	Water or steam is discharge during defrosting operation which removes frost built up on the surface of the heat exchanger in the outdoor unit in heating mode.
The outdoor unit fan is not running even when the system is in operation.	The fan speed is automatically controlled according to the ambient temperature. It may be stopped in high ambient temperature in case of heating, and in low ambient temperature in case of coding. Also, the fan is stopped during defrosting operation. [CAUTION] The fan will suddenly begin to operate even if it is stopped. Do not insert finger and/or stick.
The operation switched to fan operation during cooling operation.(in case of FDFW type)	In case the relative humidity is 73% or higher, the operation may alternate between fan operation and cooling operation even though the thermostat has not been activated. The objective of this operation mode is to prevent condensate dew formation and dew dropping from indoor unit air supply port.
The operation mode cannot be selected (in case of the heat recovery system KXR).	When operation mode is set to the main and sub indoor unit during the heat recovery system KXR, operation mode of the sub unit cannot be selected.(In this case, the system conforms to operation mode of the main unit.)
The air flow becomes weak if the operation mode is changed during operation (in case of the heat recovery	When you switch the operation mode from Cool to Heat or from Heat to Cool during operation, the air flow becomes weak for 3 minutes.

14

■ TROUBLE SHOOTING

The phenomena mentioned below is not malfunction

The indoor-unit fan will not move for several minutes during cooling	In order to protect the compressor, the indoor-unit fan may take several minutes to begin moving after beginning cooling / dehumidifying operation.		
/ dehumidifying operation (in case of the heat recovery system KXR).	Compressor protection control is automatically performed every few hours. Air flow may stop during this time; however, cooling operation will resume shortly.		
Slapping sounds are heard.	These sounds are generated when plastic components are expanded or shrunk by the heat and rubbed with each other.		
Hissing sounds are heard when the operation is stopped or during defrost operation.	These sounds are generated when the refrigerant valve inside the air conditioning system is activated.		
The air conditioner starts operation automatically as soon as the power supply is turned on.	In case the automatic restart function is enabled, and when the power supply recovers, the system restarts the operation automatically as same condition as before power supply is cut.		
The setting temperature cannot be changed (the setting temperature display flashes).	If changing the set temperature is prohibited on the remote control, it is not possible to change the temperature setting even ▼ or ▲ is pressed. ■ See page 15		
In case of wireless remote control, the unit does not operate with the inspection display light on the indoor unit flashing even though any button on the remote control is pressed.	In case the system is controlled by the other centralized remote control and it forbids operating the system from the remote control, it is not possible to operate by the remote control.		
Even if the wired remote control is operated, "central control" light only flashes and doesn't operate.	Is not "central controlling" or "center" displayed? If controlled with a separately purchased center console etc., the unit cannot be operated by the remote control.		

■ PREPARATION OF HEATING

CASES WHEN " (PREPARATION OF HEATING)" IS DISPLAYED

For wireless devices, the run/check display lamp on the main body display unit will flash green.

Setting temperature and preparation of heating are displayed on the wired remote control.

At Starting Heating Operation

In order to prevent cool air from blowing out, the air flow into the room may be stopped depending on the room temperature at the start of heating operation, please wait for a while and the operation automatically switches to the normal heating operation.

At defrost operation (during heating operation)

When frost may easily formed on the outdoor unit, the heating operation automatically is stopped (both indoor/outdoor unit stop fan operation) for approximately 5 to 10 minutes per hour and defrosting is operated. After the defrosting is complete, the 2300 DEFROS operation automatically switches back to the normal operation.



HEATING OPERATION

- Heat pump type
- Heat pump type heating applies the mechanism that draws the heat from the outside air to warm up the room by means of the refrigerant.
- Defrost operation

During heating with a heat pump type air conditioner, frost will be formed on the outdoor unit if the temperature outside the room drops. If left alone, the heating efficiency decreases. In order to deal with this, the operation is automatically switched to defrost operation to remove the frost. During the period, the air flow of indoor/outdoor unit is stopped and "heating defrost" is displayed. · Outer air temperature and heating capacity

The heating efficiency of heat pump type air conditioner decreases as the outside temperature becomes lower. If the capacity of air conditioner for heating is not sufficient, please use other heating device.

. Time required until the room temperature increases

A heat type air conditioner circulates warm air to warm the entire room, so it takes a while to rise up the room temperature. It is recommended to start operation earlier on a very cold day.

. When room temperature adjusting device operates during heating

If room temperature rises and the room temperature adjusting device is activated, the air flow becomes automatically low. When the room temperature drops, it switched back automatically to the normal operation.

AUTO RESTART < WIRED REMOTE CONTROL>

An auto restart function, which is disabled at the factory setting, is applicable to the remote control. Consult your dealer. ■ What is auto restart

- . When a power failure occurs or the power supply is turned off, the function allows the system to automatically resume operation with the remote control setting made set before the power failure when the power supply recovers. If the system is stopped before power failure it remains stopped after the power
- . Note that in the following cases it is needed to set again with the remote control.
- Timer setting is cancelled. But the sleep timer recovers after power failure recovers. When recovering from a power failure, holiday setting will override the weekly timer setting. And time setting returns to default. To return to original setting, after time setting, execute "holiday cancel".
- ② Louver stops at the horizontal position.

Make sure to stop the operation before turning off the power supply when the auto restart function is enabled. (If the power supply is turned off while the system is operating, the indoor unit fan will start immediately when the power supply is turned on. In addition, the outdoor unit starts operating 3 minutes after the power supply is turned on.)

SETTING TO DISABLE BUTTON OPERATION < Wired remote control>

The following button operations can be disabled. If the button is pressed, "OINVALID OPER" is displayed indicating that the button is disabled, and the original display returns. Consult your dealer for "DINHLID OPER" setting.

- 1 ONOFF button
- TEMP button LOUVER button
- MODE button
- ⑤ ₩ FAN SPEED button
- TIMER button

■ INSTALLATION, RELOCATION, AND INSPECTION MAINTENANCE

Please observe the following points in order to use the air conditioner in a safe and comfortable manner. Make sure to request your dealer for installation, and do not attempt to do by yourself.

INSTALLATION LOCATION

Is the system installed in a well-ventilated place?

Are there any obstacles? If so, it leads to the decrease of the efficiency and the increase of operation noise

Avoid the place where cool/warm air and operation noise cause problems to your neighbors.

ELECTRICAL WORK

Do not connect the ground wire to any gas pipe, water pipe, or wires of lightning conductors and telephones. If the ground work is not good, it may lead to electric shock.

⚠ Caution: A leakage breaker is necessary depending on the installation environment

If it is not mounted there, it may lead to electric shock.

Only qualified specialists of electrical and grounding work can do these works according to "electric equipment technical standards".

Is the wiring designated for the air conditioner?

- Is the remote control mounted correctly?
- . In the case of exposed wiring, is the wiring fixed with the attached screw?
- . Is the attached remote control clamps used for fixing the remote control cord?
- Is the remote control mounted at a height where children cannot reach?

RELOCATION

A Warning: Make sure to consult a dealer or specialist if it is required to relocate and reinstall the air conditioning system.

If the air conditioning system is installed incorrectly, water leakage, electric shock and/or fire may occur. Note that an installation fee will be charged for relocation and installation.

INSPECTION MAINTENANCE

- . Normally the efficiency of the air conditioning system will become lower after a while, because dirt accumulates inside the system. This occurs gradually in around 3 years of use, depending on the condition of use and surrounding environment. It is thus necessary to conduct inspection maintenance in addition to regular maintenance. We recommend you to consult the dealer from whom you purchased the system and make a contract for periodical inspection
- It can be easily identified on the remote control that safety equipment is operating normally. For details, refer to the instruction manual of the remote control.

OPERATION RANGE

Please use the system in the following operation range. If the system is operated outside this range, the protection controls may be activated to prevent malfunction.

Condition	Room temperature	Temperature outside the room	Humidity inside the room
Cooling operation Dry operation	Approximately 21 to 32°C Long continuous operation under approximately 21°C may lead to malfunction due to dewfall	FD series Inverter Packaged Air-Conditioners Approximately -15 to 50°C KX KXR VRF inverter multi-system Air-Conditioners Approximately -15 to 46°C	Approximately 80% or less Long operation under high humidity may leads to waterdrop or smoky vapor at the supply air grille.
Heating operation	Approximately 27°C or less	FD series Inverter Packaged Air-Conditioners Approximately -20°C to 20°C KX KXR VRF inverter multi-system Air-Conditioners Approximately -20°C to 16°C If outside air temperature becomes low, the heating efficiency is lowed and the heating becomes difficuit.	

(Note) Operation range may differ depending on models .Please check the catalog

FDU-F

Condition Operation	Outdoor air temperature
Cooling operation	20 ~ 40°C (32°C wet-bulb) Dry-bulb
Heating operation	0 ~ 24°C Dry-bulb

DRED

Descriptions of DRED models are given. Make sure it's a DRED unit.

■ This air conditioner complies with DRED standards as per AS/NZS4755.3.1. It supports demand response modes 1. 2 and 3 (DRM1, 2, and 3).

The outdoor unit of this air conditioner is equipped with a DRED-specific terminal block.

It also supports ELV(Extra-Low Voltage) as per AS/NZS60335.1.

Because the air conditioner is programmed to limit electrical power consumption when receiving the DRED input signal, cooling or heating capacity may be reduced.

In DRED-enabled mode, a small "D" is displayed on the remote controller, as shown on the pictures below. When the defrost cycle becomes active during DRED operation, touch screen controller continue to display the DRED active "D" symbol.

However, the normal controller does not; only "DEFROST" is displayed even though DRED mode remains active.

Display in DRED mode

RC-EX Series (From RC-EX Series)




RC-E Series (From RC-E Series)



Display in DRED mode during **Defrost operation**

RC-EX Series (From RC-EX Series)



RC-E Series (From RC-E Series)



■ MAINTENANCE AND INSPECTION GUIDELINE OF MAIN PARTS OF PACKAGED AIR CONDITIONER

This table indicates the details of regular inspection items and their intervals (inspection interval), and the timing of parts replacement under a normal use condition. If the equipment falls into a certain category specified by the laws and regulations of each country, conduct the maintenance and inspection according to the specified rules too. As to the preventive maintenance, the regular inspection interval is indicated as the "inspection interval," and the predicted interval of the "implementation of cleaning and adjustment" or

"implementation of parts replacement and repair" according to the result of the regular inspection is indicated as the "maintenance interval." As to the cleaning and adjustment, the timing is set to prevent the deterioration of parts and the degradation of performance. As to the parts replacement and repair after the inspection, the timing is set by estimating the operation time or use time, when the wear-out failure period is reached.

Explanation of symbols

- •: Conduct the cleaning and adjustment according to the inspection result
- ▲: In case of abnormality after inspection, replace or repair the corresponding part.





[Mainly indoor parts and built-in components]

*The distinction between the indoor and outdoor assumes the air conditioner for a store and a multiple-air conditioner for a building. This may vary depending on the configuration of the unit, such as equipment air conditioner.

Part	t Name		Regular Inspection				Preventive Maintena	ince*								
Part	t Name	Details of Inspection	Inspection Method	Criteria <standard></standard>	Details of Maintenance	Inspection	Maintenance Interval	Elapsed Years							Remarks	
		Dotaile of inteposition	mopoulon mounda	oniona solandaras	Dotaile of maintenance	Interval	(Used Hours/Duration)	1 2	3 4	5 6	7	8 9	10	11 12	13 14 15	
	Decorative panel (design part)	- Check of dirt and scratch	Visual inspection	There should be no extreme dirt, scratches, or deformation	Cleaning with neutral detergent, paintwork by repair coating		8 years					A	\vdash			Cleaning object item
Structural	Intake/outlet grills	Visual check of dirt and scratch Outlet grill louver operation check	Visual inspection	- There should be no extreme scratches or deformation	Repair or replace it if deformed or damaged Replace the bearing, motor, etc. when malfunctioning	Every year Beforetheair-	8 years					• _	+			
component	Frame, bottom plate, etc.	Check of rust and peeling off of the heat insulation material Check of peeling off and floating of paint coating	Visual inspection	There should be no extreme rust or damage of heat insulation material	If the heat insulation material is peeled off, repair and stick it Paintwork by repair coating	conditioning season	8 years				\vdash	A				Cleaning object item
	Vibration-proof rubber	- Check of deterioration and hardening of rubber	Visual and audible inspection	- Vibration insulation function should not be impaired	- Replace it when deteriorated or hardened		10 years					+	•			
	Filter	- Visual check of dirt and breakage	Visual inspection	Filter material should be seen through There should be no breakage or deformation	Clean it if it is dirty Replace it if it is broken	Every week	5 years			•		÷	+ 0		•	Consumable components
	Fan Fan casing	Visual check of vibration and balance Check of dust adhesion and appearance	Visual inspection Visual inspection	Should not be in an extremely vibrating condition There should be no extreme rust or deformation	Replace it in case of vibration and extreme unbalance Clean with a brush or wash with water in case of extreme dust adhesion		13 years							+	•	
Ventilation system parts	Fan motor	Sound audibility check Insulation resistance measurement	Audible inspection 500 V mega	- There should be no abnormal sound generation - The resistance value should be 1 $\mbox{M}\Omega$ or more	 When a bearing sound is loud, replace the bearing When the resistance value is 1 MΩ or less, replace the motor 		20,000 Hr					A				
	Bearing	- Regular lubrication is required	Audible inspection	- There should be no abnormal sound generation	- Replace parts regularly	1	15,000 Hr			-				-		Consumable components
	Automatic louver motor	- Insulation resistance, abnormal sound generation	500 V mega, audible inspection	 The resistance value should be 1 MΩ or more, there should be no abnormal sound 	- Replace it if the resistance value is 1 $\mbox{M}\Omega$ or less		20,000 Hr					A	H			
	Drain pan	Check the clogging of foreign matters and the flow of drain water Check of peeling off and floating of paint coating	Visual inspection	There should be no drainage clogging There should be no abnormal rust generation and hole opening	Cleaning of drain pan, inclination check Repair coating or replace the drain pan depending on the problem level		8 years					A				Cleaning object item
Drain system parts	Drain pump	Check the drainage condition Check the clogging and dirt of the water supply and drainage outlet Insulation resistance	Visual inspection Visual inspection 500 V mega	- Should be drained normally - There should be no clogging or dirt - The resistance value should be 1 MΩ or more	Replace it in case of drain defect Clean it in case of clogging and dirt Replace it if the resistance value is 1 MΩ or less		20,000 Hr					A _				
	Dewing preventing	- Insulation resistance, appearance check	500 V mega, visual	- The resistance value should be 1 MΩ or more,	- Replace it if the resistance value is 1 MΩ or less						\perp			+		
	heater		inspection	there should be no abnormality			20,000 Hr					<u> </u>				
	Float switch	- Operation check	Tester	- ON-OFF should operate normally	- Replace it in case of malfunction		20,000 Hr					<u> </u>	-	+		
	Air heat exchanger	Check the clogging and damage due to foreign objects Gas leakage	Visual inspection Gas detector	There should be no clogging or damage No leakage should be detected	Wash the air inflow side in case of clogging Repair or replace it when gas leakage is detected	conditioning season 20	5 years			•		•	4	•	•	Cleaning object item Due to atmospheric dirt
Refrigerant	Piping in the unit	Sympathetic vibration, contact, and corrosion of the piping in the unit Sympathetic vibration and contact of capillary tube	,	There should be no abnormal sympathetic vibration, sound, or corrosion There should be no abnormal sympathetic vibration or contact wear	Replace it or readjust the piping when extremely corroded Replace it or readjust the piping when extremely worn		20,000 Hr					A				
system parts	Electronic expansion valve	Operation check Operation sound by power on/off (pressure check)	Tactile inspection Audible and tactile inspection	Circulation of refrigerant should be felt There should be driving sound and temperature change	- Replace it when locking occurs		20,000 Hr				-	<u> </u>		+		
	Electromagnetic valve, four way switching valve, etc.	Operation and insulation performances of electromagnetic valve, four way switching valve, etc. Corrosion, abnormal sound	500 V mega Visual and audible inspection	- The resistance value should be 1 $M\Omega$ or more - There should be no abnormal sound or corrosion	- Replace it if the resistance value is 1 $\mbox{M}\Omega$ or less		20,000 Hr					A -				
	Electric component box (including inverter)	Circuit insulation resistance check Terminal part, connector looseness check	500 V mega Driver, visual inspection	- The resistance value should be 1 $M\Omega$ or more - There should be no looseness at the connecting part - There should be no deposited foreign matter - There should be no abnormal display	- Clean with a brush in case of extreme dust adhesion - Replace it if the resistance value is 1 $M\Omega$ or less - Retighten or reinsert it if there is looseness		25,000 Hr						A			
Electric and electronic parts	Switching power source transformer	- Output voltage measurement	Tester	Output voltage should be within a specified value	- Replace it if there is voltage abnormality		10 years					+				
	Temperature sensor Humidistat	- Open, short circuit, earth, appearance check	Tester, visual inspection	Should be of a specified resistance value There should be no cracking or discoloration	- Replace it in case of disconnection and short circuit		5 years			A -		+	1	+		
	Remote control switch	- Check the controllability by the operation	Visual inspection	- LCD should display as operated	- Replace it in case of failure of the following capability of control and the display		25,000 Hr					÷	A -		+	

Note 1) Random fault is an unexpected failure which occurs before the wear is progressed, within the service life of the parts and equipment. It is difficult to establish a technological measure against the random fault. At the moment, statistical handling is the only measure against the random fault.

Note 2) The elapsed year marked with * assumes the operating time as 10 hours/day and 2500 hours/year in a normal operating condition without frequent start/stop. This may vary according to the operating condition. Please check the calculation basis of the elapsed year when making a maintenance contract.

Note 3) Illustrates the estimated timing when the wear-out failure starts and how the failure rate increases as the time passes.

Note 4) The inspection timing of filter is basically every week. However, the contamination state varies depending on the type of filter and the use condition. Therefore, conduct the inspection in arbitrary cycles according to the use condition.

Explanation of symbols

- •: Conduct the cleaning and adjustment according to the inspection result
- ▲: In case of abnormality after inspection, replace or repair the corresponding part.
- . Conduct the periodic replacement (consumable components)

: Random failure : Wear-out failure

[Mainly **Outdoor** parts and built-in components]

*The distinction between the indoor and outdoor assumes the air conditioner for a store and a multiple-air conditioner for a building. This may vary depending on the configuration of the unit, such as equipment air conditioner.

	Part Name		Regular Inspection				Preventive Maintena	nance*	
	Part Name	Details of Inspection	Inspection Method	Criteria <standard></standard>	Details of Maintenance	Inspection Interval	Maintenance Interval (Used Hours/Duration)		Remarks
	Guard, etc.	Check of peeling off and floating of paint coating Check of fractures and cracks of plastic parts	Visual inspection	- There should be no extreme rust generation, cracks, fracture, etc.	Paintwork by repair coating Replace it if there is any damage, such as cracks and fracture.		8 years	A Clear	aning object item
Structural component	Frame, bottom plate,	Check of rust and peeling off of the heat insulatio material Check of peeling off and floating of paint coating	Visual inspection	There should be no extreme rust or damage of heat insulation material	If the heat insulation material is peeled off, repair and stick it Paintwork by repair coating		8 years	A Clear	aning object item
	Vibration-proof rubbe	- Check of deterioration and hardening of rubber	Visual and audible inspection	- Vibration insulation function should not be impaired	- Replace it when deteriorated or hardened		10 years	A	
	Fan Fan casing	Visual check of vibration and balance Check of dust adhesion and appearance	Visual inspection Visual inspection	Should not be in an extremely vibrating condition There should be no extreme rust or deformation	Replace it in case of vibration and extreme unbalance Clean with a brush or wash with water in case of extreme dust adhesion		10 years		
Ventilation system parts	Fan motor	Sound audibility check Insulation resistance measurement	Audible inspection 500 V mega	- There should be no abnormal sound generation - The resistance value should be 1 $\mbox{M}\Omega$ or more	- When a bearing sound is loud, replace the bearing - When the resistance value is 1 $\mbox{M}\Omega$ or less, replace the motor		20,000 Hr	A	
	Bearing	- Regular lubrication is required	Audible inspection	- There should be no abnormal sound generation	- Replace parts regularly		15,000 Hr		nsumable nponents
	Compressor	Sound audibility and vibration at the start-up, operation, and stop Insulation resistance measurement (after energizin the manufacturer designated time) Looseness of terminals and contact of wiring	Visual, audible, and tactile inspection 500 V mega Driver, visual inspection	- There should be no abnormal sound or vibration - The resistance value should be 1 M Ω or more - There should be no looseness or contact	 Replace it if abnormal Replace it if the resistance value is 1 MΩ or less Retighten. Correction of wiring path 	Every year Before the air-	20,000 Hr	A	
	Air heat exchanger	Check the clogging and damage due to foreign objects Gas leakage	Visual inspection Gas detector	There should be no clogging or damage No leakage should be detected	Wash the air inflow side in case of clogging Repair or replace it when gas leakage is detected	conditioning season	5 years		aning object item to atmospheric
Refrigerant	Piping in the unit	Sympathetic vibration, contact, and corrosion of the piping in the unit Sympathetic vibration and contact of capillary tub	· ·	There should be no abnormal sympathetic vibration, sound, or corrosion There should be no abnormal sympathetic vibration or contact wear	Replace it or readjust the piping when extremely corroded Replace it or readjust the piping when extremely worn		20,000 Hr	A	
system	Electronic expansion	Operation check Operation sound by power on/off (pressure check)	Tactile inspection Audible and tactile inspection	Circulation of refrigerant should be felt There should be driving sound and temperature change	- Replace it when locking occurs		20,000 Hr	A	
	Electromagnetic valve, way switching valve,		500 V mega Visual and audible inspection	- The resistance value should be 1 M Ω or more - There should be no abnormal sound or corrosion	- Replace it if the resistance value is 1 $M\Omega$ or less		20,000 Hr	A	
	Container, etc.	- Corrosion of accumulator, oil separator, etc.	Visual inspection	- There should be no abnormal corrosion	- Repair coating in case of corrosion generation]	20,000 Hr	A	
	Protection device (security		e Pressure gauge, etc.	Operate it at a setting value Observe the rules specified by the laws and regulations	- Replace it if it does not operate within the permissible range of setting values		25,000 Hr		
	parts) Fusible	plug - Appearance check (swelling of fusible alloy)	Visual inspection	- The fusible alloy should be in a normal position	- Replace the device if fusible alloy is swelling out of the normal position		15,000 Hr	A	

- Note 1) Random fault is an unexpected failure which occurs before the wear is progressed, within the service life of the parts and equipment. It is difficult to establish a technological measure against the random fault. At the moment, statistical handling is the only measure against the random fault.
- Note 2) The elapsed year marked with * assumes the operating time as 10 hours/day and 2500 hours/year in a normal operating condition without frequent start/stop. This may vary according to the operating condition. Please check the calculation basis of the elapsed year when making a maintenance contract.
- Note 3) illustrates the estimated timing when the wear-out failure starts and how the failure rate increases as the time passes.

Explanation of symbols

- •: Conduct the cleaning and adjustment according to the inspection result
- ▲: In case of abnormality after inspection, replace or repair the corresponding part.
- •: Conduct the periodic replacement (consumable components)

: Random failure : Wear-out failure

	Part Name		lame Regular Inspection			Preventive Maintenance*								
	Part Name		Details of Inspection	Inspection Method Criteria <standard></standard>	Details of Maintenance	Inspection	Maintenance Interval		Remarks					
			·				Interval	(Used Hours/Duration)	1 2 3 4 5	6 7 8	9 10	11 12	13 14 15	
	Crankcase he	eater	Conductivity check Insulation resistance measurement Appearance check	Tester 500 V mega Visual inspection	 It should be in a conducting state The resistance value should be 1 MΩ or more There should be no abnormality 	- Replace it if it is not in a conducting state - Replace it if the resistance value is 1 M Ω or less		8 years		•				Consumable components
	Anti-freezing heater		Conductivity check Insulation resistance, appearance check	Tester 500 V mega, visual inspection	- It should be in a conducting state - The resistance value should be 1 $\mbox{M}\Omega$ or more, there should be no abnormality	- Replace it if it is not in a conducting state - Replace it if the resistance value is 1 $\text{M}\Omega$ or less		20,000 Hr		•				
		erter) Electrolytic	Circuit insulation resistance check Terminal part, connector looseness check Capacitor (electrolytic) appearance check	500 V mega Driver, visual inspection Visual inspection	The resistance value should be 1 MΩ or more There should be no looseness at the connecting part There should be no liquid leakage or deformation	- Clean with a brush in case of extreme dust adhesion - Replace it if the resistance value is 1 $M\Omega$ or less - Retighten or re-insert it if there is looseness - Appearance check, replace it if there is liquid leakage		25,000 Hr			_			
		Smoothing capacitor	Measurement of electrical capacitance and insulation resistance Appearance check	Electrostaticinstrument, 500 V mega Tester	- Should be of specified volume or more - The resistance value should be 1 $M\Omega$ or more	- Replace parts regularly - Replace it if the resistance value is 1 $\text{M}\Omega$ or less		10 years			+			Consumable components
Electric and electronic		Terminal block	- Terminal part screw looseness, deposit of dirt	Driver, visual inspection	It should not be loose There should be no deposited foreign matter	Retighten it if it is loose. Clean with a brush in case of deposited foreign matter adhesion	Every year Beforetheair- conditioning	25,000 Hr			_	-		
parts		Electrical component (including boards, etc.)	HIC board short circuit check Visual check of dirt adhesion to the board, etc. Self-diagnosis mode, appearance check	Tester Visual inspection Visual inspection	Should be of a specified resistance value There should be no deposited foreign matter There should be no abnormal display	Replace it if it is outside the specified resistance value Clean with a brush in case of deposited foreign matter adhesion Replace or correct the part	season	25,000 Hr						
	Pressuresens sensor	sor, temperature	- Open, short circuit, earth, appearance check	Tester, visual inspection	Should be of a specified resistance value There should be no cracking or discoloration	- Replace it in case of disconnection and short circuit		5 years						
	Switch, etc. (including FFB, ELB)	Electromagnetic switch Overcurrent relay Auxiliary relay, etc.	Operation, appearance check Rough contact surface	Visual inspection Visual inspection	There should be no deformation It should operate as prescribed, there should be no deformation There should be no deformation or discoloration	Replace it in case of malfunction, deformation, and discoloration		25,000 Hr			_			
	Switching pov transformer	ver source	- Output voltage measurement	Tester	- Output voltage should be within a specified value	- Replace it if there is voltage abnormality		10 years			_			
	Cooling fan		- Insulation resistance, abnormal sound generation	500 V mega, audible inspection	- The resistance value should be 1 $\mbox{M}\Omega$ or more, there should be no abnormal sound	- Replace it if the resistance value is 1 ${\rm M}\Omega$ or less - Replace it in case of fan lock		20,000 Hr		A				
	Fuse		- Appearance check	Visual inspection	- There should be no deformation or discoloration	- Replace it when it is shutdown		10 years			+			Consumable components

- Note 1) Random fault is an unexpected failure which occurs before the wear is progressed, within the service life of the parts and equipment. It is difficult to establish a technological measure against the random fault. At the moment, statistical handling is the only measure against the random fault.
- Note 2) The elapsed year marked with * assumes the operating time as 10 hours/day and 2500 hours/year in a normal operating condition without frequent start/stop. This may vary according to the operating condition. Please check the calculation basis of the elapsed year when making a maintenance contract.

Note 3) illustrates the estimated timing when the wear-out failure starts and how the failure rate increases as the time passes.

EU DECLARATION OF CONFORMITY

We MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD. 2-3, Marunouchi 3-chome, Chiyoda-ku, Tokyo, 100-8332, Japan

declare under our sole responsibility that the apparatus referred to in this declaration conforms with the following directives.

Description of apparatus: Split Type Air Conditioner Model name:

Conformity model list

[Indoor Unit]

Category
FDE Series
FDFW Series
FDK Series
FDT Series
FDTC Series
FDTQ Series
FDTS Series
FDTW Series
FDU Series
FDUH Series
FDUM Series
FDUT Series
FDU-F Series

[Outdoor Unit]

Category
FDC - KX6 Series
FDC - KXZ Series
FDC - KXZPE1 Series
SRC - ZSX - S Series
FDC - VN Series
FDC - VNX Series
FDC - VS Series
FDC - VSX Series
FDC - VNP Series
FDC - VSA Series
FDC - VNX- A Series

Relevant EU Directives:

Machinery Directive 2006/42/EC

Applied Standards:

EN 378-2

EN 60335-1

EN 60335-2-40

Authorized representative in EU:

MHIAE SERVICES B.V.

Herikerbergweg 238, Luna ArenA, 1101 CM Amsterdam, Netherlands P.O.Box 23393 1100 DW Amsterdam, Netherlands

Note: About the detail of Conformity model, see EU DECLARATION OF CONFORMITY sheet included in a package

UK DECLARATION OF CONFORMITY

We MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD. 2-3, Marunouchi 3-chome, Chiyoda-ku, Tokyo, 100-8332, Japan

declare under our sole responsibility that the apparatus referred to in this declaration conforms with the following directives.

Description of apparatus: Split Type Air Conditioner Model name:

Conformity model list

[Indoor Unit]

Category
FDE Series
FDFW Series
FDK Series
FDT Series
FDTC Series
FDTQ Series
FDTS Series
FDTW Series
FDU Series
FDUH Series
FDUM Series
FDUT Series
FDU-F Series

[Outdoor Unit]

Category
FDC - KX6 Series
FDC - KXZ Series
FDC - KXZPE1 Series
SRC - ZSX - S Series
FDC - VN Series
FDC - VNX Series
FDC - VS Series
FDC - VSX Series
FDC - VNP Series
FDC - VSA Series
FDC - VNX- A Series

Relevant GB Directives:

Supply of Machinery (Safety) Regulations 2008 (S.I. 2008/1597)

Applied Standards:

EN 378-2

EN 60335-1

EN 60335-2-40

Authorized representative in GB:

MITSUBISHI HEAVY INDUSTRIES AIR-CONDITIONING EUROPE, LTD. 5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

Note: About the detail of Conformity model, see UK DECLARATION OF CONFORMITY sheet included in a package





MITSUBISHI HEAVY INDUSTRIES THERMAL SYSTEMS, LTD.

2-3, Marunouchi 3-chome, Chiyoda-ku, Tokyo, 100-8332, Japan (Japonya) https://www.mhi-mth.co.jp/en/

MITSUBISHI HEAVY INDUSTRIES AIR-CONDITIONING EUROPE, LTD.

5 The Square, Stockley Park, Uxbridge, Middlesex, UB11 1ET, United Kingdom

Tel: +44-333-207-4072 Fax: +44-333-207-4089 https://www.mhiae.com

MHIAE SERVICES B.V.

(Wholly-owned subsidiary of MITSUBISHI HEAVY INDUSTRIES AIR-CONDITIONING EUROPE, LTD.)

Herikerbergweg 238, Luna ArenA, 1101 CM Amsterdam, Netherlands

P.O.Box 23393 1100 DW Amsterdam, Netherlands

Tel: +31-20-406-4535

http://www.mhiaeservices.com/

MITSUBISHI HEAVY INDUSTRIES AIR-CONDITIONERS AUSTRALIA, PTY. LTD.

Block E, 391 Park Road, Regents Park, NSW, 2143 PO BOX 3167, Regents Park, NSW, 2143

Tel: +61-2-8774-7500 Fax: +61-2-8774-7501 https://www.mhiaa.com.au

MITSUBISHI HEAVY INDUSTRIES - MAHAJAK AIR CONDITIONERS CO., LTD.

220 Lad Krabang Industrial Estate Free Zone 3, Soi Chalongkrung 31, Kwang Lamplatiew,

Khet Lad Krabang, Bangkok 10520, Thailand

https://www.mhi.com/group/maco/